



JC Modular Installation Directions

Pre Install:

· Inspect the packaging and product for signs of damage and report immediately to carrier. Keep all packaging for filing a damage claim if needed. Jeeperman, LLC is not responsible for shipping damages!

This is a fairly straight forward installation for most owners taking about 30 minutes. If after reading the installation you do not feel confident in the procedure, we strongly recommend taking this to a competent shop to ensure proper installation for years of trouble free service.

It would be advisable to read these instructions, in their entirety, BEFORE starting the installation. If you are uncomfortable with this, please e-mail or contact us or seek a qualified professional installer.

Kit Contents:

4 - Grade 8 Mounting Bolts
4 - Grade 8 Nylock Nuts
1 - 3/16" Backing Plate
1 - Stainless Steel J-Hook
1 - Aluminum Knob
1 - Tie-Down Strap
And these instructions

Required tools and supplies:

SAE Wrenches and or Sockets
Lok-Tite thread locker

· Familiarize yourself with the parts. Verify all parts and hardware are accounted for and contact us if needed for any replacements. Tensioning knob may be either black or polished. Pictures are shown with a Blitz style can, other brands and styles may also be used, but may require modifications such as bottom padding etc. Blitz can is not included.

The Installation:

These installation directions are furnished as a guide; your vehicle may vary.

Items that have been modified are not returnable or exchangeable so verify compatibility first.

One person can do this installation. However, it is recommended to have helper to lift and assist.

To ease in assembly, lightly coat the hardware in assembly oil or waterproof grease. This will also protect the Zinc finished hardware from road corrosives.

· Hold JC can mount up to the tire carrier placing the vertical back plate as close to the side of installed tire as possible. Place under plates, bolts and nuts as shown (nuts on top plate at

support bases) and tighten loosely with a final alignment and centering check before tightening all bolts on support to 40 ft. lbs.

- On the backside a light or antenna tab is provided. Consult accessory manufacturers' guides concerning their installation with regards to ground or mounting specifics.

- The JTD tie down strap is the recommended method to secure a can to the JC carrier. A "J" bolt and tensioning knob is also included for alternative holding method.

Please check your local laws concerning hard mounting and transport of fuel cans with this knob or other devices including locks.

See website www.Jeeperman.com for any product updates.

If you have any questions or concerns about the product or installation, feel free to contact tech support at 509-340-3911 or info@jeeperman.com. We also welcome your feedback and input.



PHOTO 1



PHOTO 2